


# Tenob Replacement Bung Sizing



## Measuring Instructions

Bungs are sized to the actual hole size in the base. The measurement to the outside of the thread will be bigger than the hole size.

To select correctly use the measurement at **A**. It should be different to measurement **B** which is outside the threads.

To help you recognise and order the correct bung, the available replacement ones are shown below with their **A** dimension.



**BU27 - 19mm**  
Chrome



**BU32 - 31mm**



**BU37 - 31mm**



**BU42 - 18mm**



**BU47 - 18mm**



**BU52 - 19mm fine thread**



**BU52W - 19mm fine thread**



**BU62 - 16mm**



**BU295 - 16mm**



**BU302 - 21mm**



**BU307 - 21mm**



**BU392 - 40mm**



**BU397 - 40mm**



**BU29 - 19mm**  
Stainless Steel



241 Ti Rakau Drive,  
Burswood,  
Auckland  
Ph: 0800 2739180